



MED-ENG®

A BRAND OF THE SAFARILAND GROUP

EOD TOOLS BOMB BLAST SUPPRESSION BLANKET



The Bomb Blast Suppression Blanket is used to suppress and contain the blast and fragmentation from an Improvised Explosive Device (IED).

This lightweight and easily portable blanket works in conjunction with a ballistic containment ring for mitigating IEDs containing relatively smaller charges.

Use of the Blast Blanket is a **first response** option for mitigating threats in public places such as airports and public transit stations.

BOMB BLAST SUPPRESSION BLANKET

The Blanket includes lifting straps and a Ballistic Collar which is placed on its edge around the suspicious item. The Blanket is then placed over the Collar and suspicious item. The Collar directs the force of the explosive blast upwards into the Blanket which is designed to help contain fragments from an explosion.

Two or more Collars and Blast Blankets can be used to suppress a larger size item.

FEATURES

- Multiple layer ballistic filler material enclosed in a heavy duty nylon
- Fitted with lifting straps
- Both Blanket and Collar fold into a carry bag
- Standard color is black

SIZE AND PERFORMANCE

| Width | Length | Weight | Protection Level |
|----------------|----------------|---------------------|-----------------------------|
| 1.5m (4.9') | 1.5m (4.9') | 12 kg (26.5 lbs) | V50: 500m/s (1,642 ft/s) |

Figures shown above are subject to a small +/- manufacturing tolerance.



Blast Ring (above) and Blast Blanket (below), both folded to fit in the Carry Bag



Carry Bag